

Chapter 1 Introduction

GENERAL

1-1. The information in this manual may be used to compute aircraft requirements and to assist the rigger and loadmaster during joint inspection of airdrop loads. The publication containing the procedure for preparing and rigging each load is indicated with the data for the load.

SPECIAL CONSIDERATIONS

1-2. The special considerations applicable to the specific loads are given in the appropriate field manual/technical order.

