



**ARMY FM 10-526
AIR FORCE TO 13C7-2-481**



AIRDROP OF SUPPLIES AND EQUIPMENT

**RIGGING
5-TON TRUCKS**



DISTRIBUTION RESTRICTION: This publication contains technical or operational information that is for official government use only. Distribution is limited to US government agencies. Requests from outside the US government for release of this publication under the Freedom of Information Act or the Foreign Military Sales Program must be made to HQ TRADOC, Ft Monroe, VA 23651-5000.

DEPARTMENTS OF THE ARMY AND THE AIR FORCE

CHANGE
NO 1

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington, DC, 19 June 1991

**AIRDROP OF SUPPLIES AND EQUIPMENT:
RIGGING 5-TON TRUCKS**

This change adds procedures for rigging 5-ton trucks on a type V platform. Also with this change the distribution restriction statement is changed to read as follows: "DISTRIBUTION RESTRICTION. Approved for public release; distribution is unlimited." Please make this change on the cover of the basic manual. With this statement, a destruction notice is not required.

FM 10-526/TO 13C7-2-481, 2 May 1985, is changed as follows:

1. New or changed material is identified by a vertical bar in the margin opposite the changed material.
2. Remove old pages and insert new pages as indicated below:

Remove pages
i through iii
1-1 and 1-2

Glossary-1
References-1

Insert pages
i through ix
1-1 and 1-2
4-1 through 4-7
5-1 through 5-103
6-1 through 6-94
7-1 through 7-110
8-1 through 8-109
9-1 through 9-96
Glossary-1
References-1

3. File this transmittal sheet in front of the publication for reference purposes.

CHANGE
NO 2

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington, DC, 29 April 1992

**AIRDROP OF SUPPLIES AND EQUIPMENT:
RIGGING 5-TON TRUCKS**

This change revises the procedures for rigging the M925A1, 5-ton truck on a type V platform for low-velocity airdrop. Also with this change, the distribution restriction statement and the destruction notice must be changed on the cover of the basic manual and to the Change 1 transmittal page as given below.

FM 10-526/TO 13C7-2-481, 2 May 1985, is changed as follows:

1. New or changed material is identified by a vertical bar in the margin opposite the changed material.
2. Remove old pages and insert new pages as indicated below:

<u>Remove pages</u>	<u>Insert pages</u>
i through ix	i through viii
8-1 through 8-8	8-1 through 8-8
8-21 through 8-76	8-21 through 8-76
Glossary-1	Glossary-1
References-1	References-1

3. File this transmittal sheet in front of the publication for reference purposes.

DISTRIBUTION RESTRICTION: Distribution authorized to US government agencies only to protect technical or operational information from automatic dissemination under the International Exchange Program or by other means. This determination was made on 30 April 1991. Other requests for this document will be referred to Commander, US Army Quartermaster Center and School, ATTN: ATSM-DTL, Fort Lee, VA 23801-5036.

DESTRUCTION NOTICE: Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

CHANGE
NO. 3

HEADQUARTERS
DEPARTMENT OF THE ARMY
DEPARTMENT OF THE AIR FORCE
Washington, DC, 3 October 1995

AIRDROP OF SUPPLIES AND EQUIPMENT: RIGGING 5-TON TRUCKS

This change revises the procedures for rigging the M929A2 5-ton truck on a type V platform for low-velocity airdrop. Also with this change, the distribution restriction statement is changed to read as follows: **DISTRIBUTION RESTRICTION:** Distribution authorized to US government agencies only to protect technical or operational information from automatic dissemination under the International Exchange Program or by other means. This determination was made on 30 April 1991. Other requests for this document will be referred to Commander, US Army Quartermaster Center and School, ATTN: ATSM-ABN-FS, Fort Lee, VA 23801-5036. With the use of this statement, a destruction notice is required to read as follows: **DESTRUCTION NOTICE:** Destroy by any method that will prevent disclosure of contents or reconstruction of the document. Please make the above changes to the cover of the basic manual and to the Change 1 transmittal page.

FM 10-526/TO 13C7-2-481, 2 May 1985, is changed as follows:

1. New or changed material is identified by a vertical bar in the margin opposite the changed material.
2. Remove old pages and insert new pages as indicated below:

<u>Remove page</u>	<u>Insert pages</u>
i through ii	i through ii
vii through viii	vii through ix
	10-1 through 10-58
Glossary-1	Glossary-1
References-1	References-1

3. File this transmittal sheet in front of the publication for reference purposes.

DISTRIBUTION RESTRICTION: Distribution authorized to US government agencies only to protect technical or operational information from automatic dissemination under the International Exchange Program or by other means. This determination was made on 30 April 1991. Other requests for this document will be referred to Commander, US Army Quartermaster Center and School, ATTN: ATSM-ABN-FS, Fort Lee, VA 23801-5036.

DESTRUCTION NOTICE: Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

PART TWO

TYPE V AIRDROP PLATFORM

CHAPTER 4

RIGGING INFORMATION FOR TYPE V AIRDROP PLATFORM

Description of Items	4-1	4-1
Special Considerations	4-2	4-3
Modifying Truck	4-3	4-3
Accompanying Load	4-4	4-7

CHAPTER 5

**RIGGING THE M813 OR M54, 5-TON CARGO TRUCK
ON A TYPE V PLATFORM**

Section I

RIGGING TRUCK FOR LOW-VELOCITY AIRDROP

Description of Load	5-1	5-1
Preparing Platform	5-2	5-3
Building and Positioning Honeycomb Stacks	5-3	5-6
Removing Truck Components	5-4	5-17
Preparing Truck	5-5	5-17
Building Frame Support	5-6	5-28
Installing Engine Supports and Frame Support	5-7	5-30
Positioning Truck	5-8	5-33
Installing Lashings	5-9	5-35
Stowing Truck Components	5-10	5-40
Constructing and Installing Rear Suspension Sling Spreader	5-11	5-43
Stowing Body Side Racks	5-12	5-46
Constructing and Installing Front Suspension Sling Spreaders	5-13	5-47
Installing Load Cover	5-14	5-54
Installing Suspension Slings and Deadman's Tie	5-15	5-55
Stowing Cargo Parachutes	5-16	5-56
Installing Release System	5-17	5-57
Installing Extraction System	5-18	5-58
Installing Provisions for Emergency Restraints	5-19	5-60
Placing Extraction Parachutes	5-20	5-60
Marking Rigged Load	5-21	5-60
Equipment Required	5-22	5-60

Section II

RIGGING TRUCK FOR LAPE AIRDROP

Description of Load	5-23	5-66
Preparing Platform	5-24	5-66

	Paragraph	Page
Building and Positioning Honeycomb Stacks	5-25	5-68
Preparing Truck	5-26	5-80
Positioning Truck	5-27	5-84
Constructing and Installing Front Buffer Board	5-28	5-86
Installing Lashings	5-29	5-88
Installing ACB	5-30	5-96
Installing Extraction System	5-31	5-98
Placing Extraction Parachutes	5-32	5-100
Marking Rigged Load	5-33	5-100
Equipment Required	5-34	5-100

CHAPTER 6**RIGGING M817 OR M51, 5-TON DUMP TRUCK ON A TYPE V PLATFORM**

Section I

RIGGING TRUCK FOR LOW-VELOCITY AIRDROP

Description of Load	6-1	6-1
Preparing Platform	6-2	6-3
Building and Positioning Honeycomb Stacks	6-3	6-5
Removing Truck Components	6-4	6-16
Building Frame Support	6-5	6-16
Installing Engine Supports and Frame Support	6-6	6-19
Preparing Truck	6-7	6-21
Installing Load Cover	6-8	6-32
Positioning Truck	6-9	6-33
Installing Lashings	6-10	6-36
Building Suspension Sling Spreaders	6-11	6-41
Installing Suspension Sling Spreaders	6-12	6-45
Installing Suspension Slings and Deadmen's Tie	6-13	6-49
Stowing Cargo Parachutes	6-14	6-50
Installing Release System	6-15	6-51
Installing Extraction System	6-16	6-52
Installing Provisions for Emergency Restraints	6-17	6-53
Placing Extraction Parachutes	6-18	6-53
Marking Rigged Load	6-19	6-53
Equipment Required	6-20	6-53

Section II

RIGGING TRUCK FOR LAPE AIRDROP

Description of Load	6-21	6-58
Preparing Platform	6-22	6-58
Building and Positioning Honeycomb Stacks	6-23	6-60
Preparing Truck	6-24	6-71
Installing ACB	6-25	6-71
Positioning Truck	6-26	6-77
Installing Lashings	6-27	6-79
Installing Extraction System	6-28	6-87
Placing Extraction Parachutes	6-29	6-90
Marking Rigged Load	6-30	6-90
Equipment Required	6-31	6-90

		Paragraph	Page
CHAPTER 7	RIGGING M925, 5-TON CARGO TRUCK ON A TYPE V PLATFORM		
Section I	RIGGING TRUCK FOR LOW-VELOCITY AIRDROP		
	Description of Load	7-1	7-1
	Preparing Platform	7-2	7-3
	Building and Positioning Honeycomb Stacks	7-3	7-6
	Removing Truck Components	7-4	7-23
	Preparing Truck	7-5	7-23
	Building Frame Support	7-6	7-39
	Installing Engine Supports and Frame Support	7-7	7-43
	Positioning Truck	7-8	7-45
	Constructing and Installing Front Suspension		
	Sling Spreaders	7-9	7-47
	Installing Lashings	7-10	7-52
	Constructing and Installing Rear Suspension Sling		
	Spreader	7-11	7-57
	Installing Suspension Slings and Antitumble		
	Slings	7-12	7-60
	Installing Load Cover and Deadman's Tie	7-13	7-63
	Stowing Cargo Parachutes	7-14	7-64
	Installing Release System	7-15	7-65
	Installing Extraction System	7-16	7-66
	Installing Provisions for Emergency Restraints	7-17	7-67
	Placing Extraction Parachutes	7-18	7-67
	Marking Rigged Load	7-19	7-67
	Equipment Required	7-20	7-67
Section II	RIGGING TRUCK FOR LAPE AIRDROP		
	Description of Load	7-21	7-75
	Preparing Platform	7-22	7-75
	Building and Positioning Honeycomb Stacks	7-23	7-77
	Removing Truck Components	7-24	7-81
	Preparing Truck	7-25	7-81
	Building Frame Support	7-26	7-87
	Installing Engine Supports and Frame Support	7-27	7-87
	Positioning Truck	7-28	7-87
	Installing Clevises and Spring Restraint Straps	7-29	7-91
	Installing Lashings	7-30	7-93
	Installing Load Cover	7-31	7-98
	Installing ACB	7-32	7-99
	Installing Extraction System	7-33	7-101
	Placing Extraction Parachutes	7-34	7-105
	Marking Rigged Load	7-35	7-105
	Equipment Required	7-36	7-105
CHAPTER 8	RIGGING M925A1, 5-TON CARGO TRUCK ON A TYPE V PLATFORM		
Section I	RIGGING TRUCK FOR LOW-VELOCITY AIRDROP		
	Description of Load	8-1	8-1
	Preparing Platform	8-2	8-3

Paragraph Page

Building and Positioning Honeycomb Stacks	8-3	8-6
Removing Truck Components	8-4	8-25
Preparing Truck	8-5	8-25
Building Frame Support	8-6	8-40
Installing Engine Supports and Frame Support	8-7	8-43
Positioning Truck	8-8	8-45
Constructing and Installing Front Suspension		
Sling Spreaders	8-9	8-47
Installing Lashings	8-10	8-52
Constructing and Installing Rear Suspension		
Sling Spreader	8-11	8-58
Securing Spare Tire	8-12	8-61
Securing, Lashing, and Covering Troop Seats	8-12.1	8-63
Installing Suspension Slings and Antitumble		
Slings	8-13	8-66
Installing Deadman's Tie and Safety Tie	8-14	8-69
Stowing Cargo Parachutes	8-15	8-70
Installing Release System	8-16	8-72
Installing Extraction System	8-17	8-73
Installing Provisions for Emergency Restraints	8-18	8-74
Placing Extraction Parachutes	8-19	8-74
Marking Rigged Load	8-20	8-74
Equipment Required	8-21	8-74

Section II

RIGGING TRUCK FOR LAPE AIRDROP

Description of Load	8-22	8-76
Preparing Platform	8-23	8-76
Building and Positioning Honeycomb Stacks	8-24	8-78
Removing Truck Components	8-25	8-82
Preparing Truck	8-26	8-82
Building Frame Support	8-27	8-85
Installing Engine Supports and Frame Support	8-28	8-85
Positioning Truck	8-29	8-85
Installing Clevises and Spring Restraint Straps	8-30	8-89
Installing Lashings	8-31	8-91
Installing Load Cover	8-32	8-97
Installing ACB	8-33	8-98
Installing Extraction System	8-34	8-100
Placing Extraction Parachutes	8-35	8-104
Marking Rigged Load	8-36	8-104
Equipment Required	8-37	8-104

CHAPTER 9

RIGGING M929, 5-TON DUMP TRUCK ON A TYPE V PLATFORM

Section I

RIGGING TRUCK FOR LOW-VELOCITY AIRDROP

Description of Load	9-1	9-1
Preparing Platform	9-2	9-2
Building and Positioning Honeycomb Stacks	9-3	9-5
Removing Truck Components	9-4	9-22
Preparing Truck	9-5	9-22

	Paragraph	Page
Building Frame Support	9-6	9-29
Installing Engine Supports and Frame Support	9-7	9-33
Constructing and Installing Rear Suspension		
Sling Spreader	9-8	9-35
Positioning Truck	9-9	9-38
Constructing and Installing Front Suspension		
Sling Spreaders	9-10	9-41
Installing Lashings	9-11	9-46
Constructing, Positioning and Securing		
Parachute Stowage Platform	9-12	9-50
Installing Suspension Slings and Antitumble Slings	9-13	9-52
Installing Load Cover and Deadman's Tie	9-14	9-54
Stowing Cargo Parachutes	9-15	9-55
Installing Release System	9-16	9-56
Installing Extraction System	9-17	9-57
Installing Provisions for Emergency Restraints	9-18	9-58
Placing Extraction Parachute	9-19	9-58
Marking Rigged Load	9-20	9-58
Equipment Required	9-21	9-58
Section II		
RIGGING TRUCK FOR LAPE AIRDROP		
Description of Load	9-22	9-65
Preparing Platform	9-23	9-65
Building and Positioning Honeycomb Stacks	9-24	9-68
Removing Truck Components	9-25	9-72
Preparing Truck	9-26	9-72
Building Frame Support	9-27	9-75
Installing Engine Supports and Frame Support	9-28	9-75
Positioning Truck	9-29	9-75
Installing Clevises and Spring Restraint Straps	9-30	9-77
Constructing and Installing a Front Buffer		
Board	9-31	9-79
Installing Lashings	9-32	9-81
Installing ACB	9-33	9-85
Installing Extraction System	9-34	9-87
Placing Extraction Parachutes	9-35	9-91
Marking Rigged Load	9-36	9-91
Equipment Required	9-37	9-91
CHAPTER 10		
RIGGING M929A2, 5-TON DUMP TRUCK ON		
A 32-FOOT, TYPE V PLATFORM		
FOR LOW-VELOCITY AIRDROP		
Description of Load	10-1	10-1
Preparing Platform	10-2	10-1
Building and Positioning Honeycomb Stacks	10-3	10-1
Removing Truck Components	10-4	10-17
Preparing Truck	10-5	10-17
Building Frame and Installing Support	10-6	10-21
Building and Installing Front Sling Spreader	10-7	10-25

	Paragraph	Page
Building and Installing Middle Sling Spreader	10-8	10-26
Building and Installing Rear Sling Spreader	10-9	10-29
Installing Heavy-Duty Derigging System and Positioning Truck	10-10	10-32
Installing Lashings	10-11	10-35
Preparing Hard Overhead Cab Cover	10-12	10-38
Installing Spare Tire and Hard Cab Cover	10-13	10-40
Lashing Cab Cover and Middle Sling Spreader to Platform	10-14	10-43
Installing and Safetying Suspension Slings	10-15	10-45
Installing Load Cover	10-16	10-47
Building and Installing Parachute Stowage Platform	10-17	10-48
Stowing Cargo Parachutes	10-18	10-50
Installing Extraction System	10-19	10-51
Installing Release System	10-20	10-52
Installing Provisions for Emergency Restraints	10-21	10-52
Placing Extraction Parachute	10-22	10-53
Marking Rigged Load	10-23	10-53
Equipment Required	10-24	10-55
GLOSSARY		Glossary-1
REFERENCES		References-1

PREFACE

Scope

a. This manual tells and shows how to rig the following series of trucks for low-velocity airdrop from a C-130, C-141, or C-5 aircraft:

- (1) M813, 5-ton cargo truck
- (2) M54, 5-ton cargo truck
- (3) M925, 5-ton cargo truck
- (4) M925A1, 5-ton cargo truck
- (5) M51, 5-ton dump truck
- (6) M817, 5-ton dump truck
- (7) M929, 5-ton dump truck
- (8) M929A2, 5-ton dump truck

b. This manual also covers the rigging of the following items for delivery by LAPE airdrop from a C-130 aircraft:

- (1) M813, 5-ton cargo truck
- (2) M54, 5-ton cargo truck
- (3) M925, 5-ton cargo truck
- (4) M925A1, 5-ton cargo truck
- (5) M51, 5-ton dump truck
- (6) M817, 5-ton dump truck
- (7) M929, 5-ton dump truck

User Information

The proponent of this publication is HQ TRADOC. You are encouraged to report any errors or omissions and suggest ways for making this a better manual. Army personnel, send your comments on DA Form 2028 directly to:

Commander
US Army Quartermaster Center and School
ATTN: ATSM-ABN-FS
Fort Lee, Virginia 23801-5036

Air Force personnel, send your reports on AFTO Form 22 through:

Headquarters
Military Airlift Command (MAC/XOTX)
402 Scott Drive Unit 3A1
Scott AFB, Illinois 62225-5302

to:

Commander
US Army Quartermaster Center and School
ATTN: ATSM-ABN-FS
Fort Lee, Virginia 23801-5036

Also send information copy of AFTO Form 22 to:

San Antonio ALC/MMEDTA
Kelly AFB, Texas 78214-5000