ARMY FM 10-527
AIR FORCE TO 13C7-10-191

AIRDROP OF SUPPLIES AND EQUIPMENT
RIGGING
155-MM HOWITZERS



DEPARTMENTS OF THE ARMY AND THE AIR FORCE

CHANGE
NO 3

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington, DC, 10 September 1993

AIRDROP OF SUPPLIES AND EQUIPMENT
RIGGING 155-MM HOWITZERS

This change modifies the procedures for rigging the M198, 155-mm howitzer with accompanying ammunition load on a type V platform for low-velocity and LAPE airdrop. Also with this change, the C-5 aircraft may be used for low-velocity airdrop. See FM 10-500-2 for guidance when rigging loads for the C-5 aircraft. Please make this change where it applies throughout the manual.

FM 10-527/TO 13C7-10-191, 30 September 1982, is changed as follows:

1. New or changed material is identified by a vertical bar in the margin opposite the changed material.

2. Remove old pages and insert new pages as indicated below.

Remove old pages	Insert new pages
i through v	i through v
5-35 through 5-83	5-35 through 5-84

3. File this transmittal sheet in front of the publication for reference purposes.

DISTRIBUTION UNLIMITED

DESTRUCTION NOTICE. Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

By Order of the Secretaries of the Army and the Air Force:

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army
05077

DISTRIBUTION:

Active Army, USAR, and ARNG: To be distributed in accordance with DA Form 12-11-E, requirements for FM 10-527, Airdrop of Supplies and Equipment: Rigging 155-MM Howitzers (Qty rqr block no. 0910).

CHANGE
NO. 2

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington, DC, 15 June 1992

AIRDROP OF SUPPLIES AND EQUIPMENT

RIGGING 155-MM HOWITZERS

This change adds procedures for rigging the M198, 155-mm howitzer with accompanying ammunition load on a type V platform for low-velocity and LAPE airdrop. Also with this change, the distribution statement and destruction notice must be added to the cover of the basic manual as shown below. Also change the distribution restriction statement on the change 1 transmittal page to agree with the statement below.

FM 10-527/TO 13C7-10-191, 30 September 1982, is changed as follows:

1. New or changed material is identified by a vertical bar in the margin opposite the changed material.

2. Remove old pages and insert new pages as indicated below:

Remove Pages	**Insert Pages**
i through vii	i through iv
4-31 and 4-32	4-31 and 4-32
	5-1 through 5-83
Glossary-1	Glossary-1
A-1	References-1

3. File this transmittal sheet in front of the publication.

DISTRIBUTION UNLIMITED

DESTRUCTION NOTICE: Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

CHANGE
NO 1

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington ,DC, 27 September 1988

AIRDROP OF SUPPLIES AND EQUIPMENT: RIGGING 155-MM HOWITZERS

This change adds the procedures for rigging the M198, 155-mm howitzer for low-velocity and LAPE airdrop on the type V platform.

FM 10-527/TO 13C7-10-191, 30 September 1982, is changed as follows:

1. Remove old pages and insert new pages as indicated below:

Remove pages	Insert pages
i through iv	i through vii
1-1 and 1-2	1-1 and 1-2
2-1 and 2-2	2-1 and 2-2
2-5 through 2-8	2-5 through 2-8
2-21 through 2-26	2-21 through 2-26
3-1 and 3-2	3-1 and 3-2
3-27 through 3-30	3-27 through 3-30
	4-1 through 4-52
A-1	A-1

2. New or changed material is identified by a vertical bar in the margin opposite the changed material.
3. File this transmittal sheet in front of the publication for reference purposes.

DISTRIBUTION UNLIMITED

DESTRUCTION NOTICE. Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

FIELD MANUAL
NO 10-527
TECHNICAL ORDER
NO 13C7-10-191

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington, DC, 30 September 1982

AIRDROP OF SUPPLIES AND EQUIPMENT
RIGGING 155-MM HOWITZERS

TABLE OF CONTENTS

		Paragraph	Page
PREFACE			v
CHAPTER 1	INTRODUCTION		
	Description of Items	1-1	1-1
	Special Considerations	1-2	1-1
CHAPTER 2	RIGGING M198, 155-MM HOWITZER ON TYPE II OR LAPE PLATFORM		
Section I	RIGGING HOWITZER FOR LOW-VELOCITY AIRDROP ON TYPE II PLATFORM		
	[redacted]	2-1	2-1
		2-2	2-1
		2-3	2-2
		2-4	2-5
		2-5	2-6
		2-6	2-13
	TYPE II PROCEDURES REMOVED	2-7	2-14
		2-8	2-14
		2-9	2-17
		2-10	2-18
		2-11	2-19
		2-11.1	2-21
		2-12	2-21

DISTRIBUTION UNLIMITED

DESTRUCTION NOTICE. Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

*This manual supersedes FM 10-527/TO 13C7-10-191, 15 August 1975.

		Paragraph	Page
	TYPE II PROCEDURES REMOVED	.2-13	2-22
		.2-14	2-23
		.2-15	2-23
SECTION II	**RIGGING HOWITZER FOR LAPE AIRDROP ON LAPE PLATFORM**		
	REMOVED: 95 MESSAGE TERMINATION OF LAPES	.2-16	2-26
		.2-17	2-26
		.2-18	2-26
		.2-19	2-26
		.2-20	2-30
		.2-21	2-30
		.2-22	2-30
		.2-23	2-30
		.2-24	2-34
		.2-25	2-36
		.2-26	2-36
		.2-27	2-36
CHAPTER 3	**RIGGING M114A1, 155-MM HOWITZER ON TYPE II OR LAPE PLATFORM**		
SECTION I	**RIGGING HOWITZER FOR LOW-VELOCITY AIRDROP ON TYPE II PLATFORM**		
	TYPE II PROCEDURES REMOVED	.3-1	3-1
		.3-2	3-1
		.3-3	3-2
		.3-4	3-8
		.3-5	3-10
		.3-6	3-11
		.3-7	3-16
		.3-8	3-17
		.3-9	3-17
		.3-10	3-20
		.3-11	3-21
		.3-12	3-23
		.3-13	3-25
		.3-14	3-25
		.3-15	3-26
		.3-16	3-26
		.3-17	3-27
Section II	**RIGGING HOWITZER FOR LAPE AIRDROP ON LAPE PLATFORM**		
	REMOVED: 95 MESSAGE TERMINATION OF LAPES	3-18	3-30
		3-19	3-30

		Paragraph	Page
	REMOVED: 95 MESSAGE TERMINATION OF LAPES	3-20	3-31
		3-21	3-36
		3-22	3-38
		3-23	3-38
		3-24	3-39
		3-25	3-39
		3-26	3-42
		3-27	3-43
		3-28	3-44
		3-29	3-45
		3-30	3-46
CHAPTER 4	**RIGGING M198, 155-MM HOWITZER ON TYPE V PLATFORM**		
Section I	**RIGGING HOWITZER FOR LOW-VELOCITY AIRDROP**		
	Description of Load	4-1	4-1
	Preparing Platform	4-2	4-1
	Building and Placing Honeycomb Stacks	4-3	4-3
	Stowing Accompanying Equipment	4-4	4-8
	Preparing Howitzer	4-5	4-10
	Installing Suspension Slings	4-6	4-21
	Setting Howitzer on Platform	4-7	4-22
	Lashing Howitzer	4-8	4-22
	Covering Load and Safetying Slings	4-9	4-24
	Stowing Cargo Parachutes	4-10	4-25
	Installing Extraction System	4-11	4-28
	Installing Emergency Restraint	4-12	4-28
	Installing Release System	4-13	4-30
	Placing Extraction Parachute	4-14	4-31
	Marking Rigged Load	4-15	4-32
	Equipment Required	4-16	4-33
Section II	**RIGGING HOWITZER FOR LAPE AIRDROP**		
	REMOVED: 95 MESSAGE TERMINATION OF LAPES	4-17	4-35
		4-18	4-35
		4-19	4-36
		4-20	4-41
		4-21	4-43
		4-22	4-43
		4-23	4-43
		4-24	4-44
		4-25	4-48
		4-26	4-50
		4-27	4-50
		4-28	4-51

		Paragraph	Page
CHAPTER 5	RIGGING M198, 155-MM HOWITZER WITH ACCOMPANYING AMMUNITION LOAD ON A TYPE V PLATFORM		
Section I	LOW-VELOCITY AIRDROP		
	Description of Load	5-1	5-1
	Preparing Platform	5-2	5-1
	Rigging Accompanying Ammunition Load	5-3	5-4
	Preparing and Positioning Honeycomb Stacks	5-4	5-14
	Stowing Accompanying Equipment	5-5	5-22
	Preparing Howitzer	5-6	5-29
	Installing Lifting Slings and Positioning Howitzer	5-7	5-29
	Lashing Howitzer	5-8	5-31
	Building and Installing Release Stowage Platform	5-9	5-36
	Covering Load	5-10	5-38
	Installing Suspension Slings and Deadman's Tie	5-11	5-40
	Stowing Cargo Parachutes	5-12	5-42
	Installing Extraction System	5-13	5-48
	Installing Release System	5-14	5-49
	Installing Provisions for Emergency Restraints	5-15	5-50
	Placing Extraction Parachute	5-16	5-50
	Marking Rigged Load	5-17	5-50
	Equipment Required	5-18	5-50
Section II	LAPE AIRDROP		
	[redacted]	5-19	5-55
		5-25	5-55
		5-21	5-57
		5-22	5-63
		5-23	5-71
		5-24	5-74
		5-25	5-74
		5-26	5-74
		5-27	5-76
		5-28	5-80
		5-29	5-82
		5-30	5-82
		5-31	5-82

REMOVED: 95 MESSAGE TERMINATION OF LAPES

GLOSSARY Glossary-1

REFERENCES References-1

PREFACE

SCOPE

This manual tells and shows how to rig the M198, 155-mm howitzer on the type II, type V, and LAPE platforms for low-velocity airdrop from C-130, C-141, and C-5 aircraft. This manual also tells and shows how to rig the M198, 155-mm howitzer on the LAPE and type V platforms for LAPE airdrop from C-130 aircraft. In addition, this manual tells and shows how to rig the M114A1, 155-mm howitzer on the type II and LAPE platforms for low-velocity airdrop from C-130 aircraft and on the LAPE platform for LAPE airdrop from C-130 aircraft. The procedures for rigging an accompanying ammunition load with the M198, 155-mm howitzer on a type V platform for low-velocity airdrop from the C-5 and C-141 aircraft and for LAPE airdrop from the C-130 and C-141 aircraft are given. This manual is designed for use by all parachute riggers.

USER INFORMATION

The proponent of this publication is HQ TRADOC. You are encouraged to report any errors or omissions and to suggest ways for making this a better manual. Army personnel, send your comments on DA Form 2028 directly to:

Commander
US Army Quartermaster Center and School
ATTN: ATSM-SPT-I
Fort Lee, Virginia 23801-5036

Air Force personnel, send your reports on AFTO Form 22 through:

HQ AMC/XOTT
402 Scott Drive, Unit 3A1
Scott AFB, Illinois 62225-5302

to:

Commander
US Army Quartermaster Center and School
ATTN: ATSM-SPT-I
Fort Lee, Virginia 23801-5036

Also send information copies of AFTO Form 22 to:

San Antonio ALC/LDILT
Kelly AFB, Texas 78241-5000